Manual

Cash organizer

InsertTill-250

Table of contents

Specifications: 3
Maintenance: 4
Safety: 4

Specifications:

- **Warranty:** 1 year
- **Color:** Black
- **Material:** ABS, Steel
- **Number of compartments:** 3 compartments for banknotes, 3 compartments for coins
- **Dimensions of the banknote compartments:** W 7.8 cm, 7.5 cm, 7.5 cm x L 16.3 cm
- **Banknote security features:** stainless steel snaps with spring mechanism
- **External dimensions:** 24.5 cm (W) × 24.2 cm (L) × 3.5 cm (H)
- **Product Weight:** 0.4kg

Maintenance:

- **Surface cleaning** – Clean the cartridge regularly with a soft, dry cloth or damp cloth to remove dust and dirt. Do not use harsh detergents or solvents.
- **Protect metal components** – Latches for banknotes and other metal parts can be gently wiped with a cloth soaked in silicone oil to prevent corrosion and ensure smooth operation.
- **Mechanism inspection** – check the spring mechanism of the latches every few months. If you notice a voltage drop or difficulty in operation, gently lubricate the moving parts with a special technical grease.

Safety:

- When inserting and removing cash, avoid excessive force so as not to damage the banknote latch mechanism.
- The cartridge should be stored in a dry place to prevent corrosion of metal components and damage to the plastic.