Manual

Banknote Tester

MoneyCheck-09

Table of contents

Specifications: 3
Set contents: 4
Safety: 4
Usage: 5
Maintenance: 5

Specifications:

- **Warranty:** 1 year
- **Material:** ABS
- **Functions:** UV (Ultraviolet Light)
- **Power supply:** mains, rechargeable
- **Voltage:** AC100V-240V, 50/60Hz
- **UV Power:** 3W
- **Power:** 6W
- **Operating temperature:** 0-45°C
- **Operating Humidity:** ≤85%
- **Device dimensions:** 20 x 10.5 x 10 cm
- **Package dimensions:** 20.5 x 11 x 11.5 cm
- **Device weight:** 450 g
- **Package weight:** 540 g

Set contents:

- Banknote Tester,
- USB C cable,
- Manual.

Safety:

WARNING

1. Do not look directly at the ultraviolet light source for long periods of time.
2. Do not place the device where it may be exposed to water or other liquids.
3. Always unplug the appliance from the socket before cleaning it. Do not use liquid cleaners or aerosols.
4. Do not disassemble the device. If repairs are needed, take them to a qualified service center.
5. Do not use the device in places with high temperature or humidity, as this may cause it to malfunction.

REMARK

1. Do not use the device if the USB cable is damaged.
2. Do not place objects on the power cord and do not bend it excessively.
3. When the appliance is not in use for a long period of time, unplug the power cord from the outlet.

Usage:

Note: Before you start verifying a banknote or document, make sure that you know and understand the security features of the banknote or document you are checking. This will help you use the device properly.



I: UV light on
O: Off

Plug in the device and turn it on by sliding the switch from the "O" to "I" position. Place the banknote or document under UV light. If the banknote contains UV ink or other fluorescent security features, they will glow.

Maintenance:

- Avoid using the device near strong natural or artificial light sources.
- Strong natural or artificial light can suppress the effect of UV light, reducing the visibility of fluorescence on the banknote or document being analyzed.
- Do not use the appliance in areas exposed to water or other liquids.
- Dust can accumulate on UV lamps, reducing their brightness. Use a damp, soft cloth to clean. Do not use liquid cleaners or aerosols.
- Unplug the appliance from the outlet before cleaning or replacing the lamp.

- Do not use the appliance if the power cord is damaged or the plug is loose. Failure to follow these guidelines could result in electric shock, fire, or other hazards.
- If the appliance is not used for a long period of time, unplug from the socket.