Manual

Money organizer for cash drawer

HD-WS35

Table of contents

Specifications: 3
Maintenance 4
Safety 4

Specification:

- **Warranty:** 1 year
- **Color:** Black
- **Material:** ABS plastic, SECC metal plate
- **Number of banknote compartments:** 4
- **Dimensions of the banknote compartments:** 2 compartments of 7 cm x 17.5 cm, 1 compartment of 7.5 cm x 17.5 cm, 1 compartment of 8.3 cm x 17.5 cm
- **Number of coin compartments:** 8
- **Banknote security:** stainless steel snaps with spring mechanism
- **Additional functions:** adjustable compartments for coins and banknotes, compartment under the coin insert for other means of payment
- **Insert dimensions:** 31.2 (W) x 30.6 (L) x 5.5 (H) cm
- **Package dimensions:** 37 x 33.5 x 6.5 cm
- **Cartridge weight:** 1 kg
- **Compatible drawer models:** HD-KR35

Maintenance

- Use a soft, damp cloth to clean. Avoid using harsh detergents or solvents that can damage the surface of the cartridge.
- Make sure the cartridge is stored in a dry place. Excessive moisture can lead to corrosion of metal components or deformation of plastic parts.
- Regularly check that the bill holders are running smoothly. In case of jamming, gently lubricate the mechanism with a suitable grease designed for small parts.
- Overfilling the insert can lead to damage to the dividers. Take care of the even distribution of money.

Safety

- The insert is intended for storing banknotes and coins only. It should not be used for other purposes, such as storing sharp objects or chemicals.
- Always store the cartridge in a closed cash drawer to minimize the risk of theft.
- Avoid sudden movements when moving a cartridge filled with money to prevent it from spilling out.
- The product is not a toy. Prevent access by children to avoid the risk of accidental damage or swallowing of small parts.