User Manual

Connecting a TimeLok time recorder to a BeepClock account

BEEPCLOCK

HDWR
Hardware for business

# Connecting the TimeLok device to the BeepClock service server

1. **Press the MENU button on the keyboard**
2. **Select the "Settings" tile from the menu**


3. **Select the "Communication" tile**

**4.** **From the list that appears, select the item „Web server URL"**

5. **In the window that opens, enter the following server address:**

*wss://timelok.beepclock.com*

Adding a device to the BeepClock panel

1. Log in to the panel at app.beepclock.com

## 2. From the menu on the left, select "Devices"

3. Press the "Add New Device" button

**4. On the TimeLok device, press the MENU and then go to "Sys Info"**

5. Select the "Device Info" tile and locate the field described as Serial Number.

6. Serial Number of the device (Serial Number), enter in the "Serial Number" field in the device configuration.


Numer seryjny
202402154

Nazwa
Wejście

Opis

ZAPISZ

7. Give a name to the device (e.g. main entrance), add an optional description and press the "Save" button

ZAPISZ

The device and your account are ready to enter employees and generate reports.

HDWR
Hardware for business

In order to receive additional information about the purchased device or detailed technical assistance as well as information on the conditions of return of purchased devices and their warranty, please visit our website

hdwrglobal.com

HDWR
Hardware for business