

Statement

Programming the #
character as a suffix

HD67

To set # as a suffix on the HD67, scan the following codes one by one.

