

# User Manual

---

## Wireless 2D Code Scanner **HD-LR66**

# Table of contents

- Specifications: ..... 3
- Set contents:..... 4
- Features: ..... 4
- Basic configuration codes: ..... 4
- Stock mode settings:..... 5
- Operating mode settings and battery:..... 5
- Wireless settings:.....7
- Audio settings:..... 8
- Suffix settings (end characters): ..... 8

## Specifications:

- **Warranty:** 2 years
- **Light Source:** 617nm LED
- **Scanning method:** manual (push-button), autootoc
- **Scan confirmation:** light and sound
- **Scan speed:** 300 scans/second
- **Wireless Communication:** Bluetooth, 2.4G
- **Interface:** USB
- **Drop resistance:** up to 1.5 meters
- **Device dimensions:** 18 x 14.5 x 9.5 cm
- **Package dimensions:** 18 x 14.5 x 9.5 cm
- **Reader weight:** 450 g
- **Weight of the device with packaging:** 525 g
- **Operating Temperature:** -20~50°C
- **Storage Temperature:** -30~60°C
- **Readable 1D codes:** UPC/EAN, ISBN, ISSN, Code39, Code 39Full ASCII, Code32, Code128, Code11, Code93, Coda bar, industrial 2 of 5, Interleaved 2 of 5, MSI, GS1 Data Bar
- **Readable 2D codes:** QR, Micro QR, Data Matrix, PDF417, MicroPDF417, Aztec Code, Maxi Code, Hanxin

## Set contents:

- Wireless 2D Code Reader
- Dock
- USB cable
- Manual


## Features:

- **Scan speed:** 300 scans/second
- **Wireless communication type:** Bluetooth, 2.4 G
- **Scan confirmation:** light and sound
- **Drop resistance:** up to 1.5 meters

## Basic configuration codes:



Factory reset



Pairing the reader with the docking station



Auto mode on



Auto mode off

Stock mode settings:



Real-world mode



Stock mode



Data transfer









Memory Cleanup

Operating mode settings and battery:



Show battery status

 90s	 2min*
 5min	 30min
 60min	 166min40s

Set the amount of time after which the scanner should go into sleep mode



Always-on scanner  
(do not go into sleep mode)



Instant Sleep

Wireless settings:



Bluetooth Mode



2.4G mode



Bluetooth-HID



Bluetooth-SPP



Bluetooth-BLE

Audio settings:



Turn on the sound



Turn off the sound



Low volume



Medium volume



High volume

Suffix settings (end characters):



CR



LF



TAB



CR+LF



No end sign