


RS232 cable diagram

Wired barcode reader

HD10C



1. DCD - Data Carrier Detect
2. TxD - Transmitted Data
3. RxD - Received Data
4. DTR - Data Terminal Ready
5. GND - Common Ground
6. DSR - Data Set Ready
7. RTS - Request To Send
8. CTS - Clear To Send
9. RI - Ring Indicator