

Manual

Barcode Reader with Stand

HD32A

Table of contents

Specifications:.....	2
Kit contents:.....	3
Factory Reset.....	4
Code Scan Mode Settings.....	4
Beep settings.....	4
Interface Settings.....	5
End-character settings.....	5
Case settings.....	6


Specifications:

- **Warranty:** 2 years
- **Light Source:** 650±20nm VLD
- **Scan Method:** Manual (On Button) / Automatic (When Code Is Zoomed In)
- **Scan confirmation:** light and sound
- **Scan Speed:** 300 scans/second
- **Interface:** USB
- **Drop resistance:** up to 1.5 meters
- **Dimensions of the device:** 18 x 14.5 x 9.5 cm
- **Package dimensions:** 18 x 14.5 x 9.5 cm
- **Reader weight:** 350 g
- **Weight of the device with packaging:** 420 g
- **Operating Temperature:** -20~50°C
- **Storage Temperature:** -40~70°C
- **ID CODE READS:** UPC/EAN, ISBN, ISSN, Code39, Code 39Full ASCII, Code32, Code128, Code11, Code93, Coda bar, industrial 2 of 5, Interleaved 2 of 5, MSI, GSI Data Bar


Kit contents:

- Wired Barcode Reader
- Saucer
- USB cable
- Manual

Factory Reset




Code Scan Mode Settings



Beep settings






Interface Settings



End-character settings





CR + LF



Tab



No trailing character

Case settings



Conversion to lowercase letters



All lowercase letters



All uppercase letters



No case replacement (default)