Manual

Banknote Tester

MoneyCheck-11

Table of contents

Specifications: 3
Set contents: 4
Safety: 4
Usage: 4
Detection of counterfeit banknotes using ultraviolet light 5
Magnetic Ink Detection 5
Watermark and microtext verification 5
Verify microtext with a magnifying glass 5
Maintenance: 6

Specifications:

- **Warranty:** 1 year
- **Material:** ABS
- **Functions:** UV (Ultraviolet Light), MG (Magentic Detection), WM (Watermark), MGF (Magetic Fibers)
- **Power supply:** mains, rechargeable
- **Voltage:** AC100V-240V, 50/60Hz
- **UV Power:** 3W x 2, LED
- **Power:** 5W
- **Operating temperature:** 0-45°C
- **Operating Humidity:** ≤85%
- **Device dimensions:** 18.5 x 10.5 x 10.5 cm
- **Package dimensions:** 20.5 x 11 x 11.5 cm
- **Device weight:** 500 g
- **Weight with packaging:** 620 g

Set contents:


- Banknote Tester,
- USB C cable,
- Manual.

Safety:

- Do not use the device in places with high temperature or high humidity, as this may cause it to malfunction.
- Do not disassemble the device. Incorrect assembly when unfolded may result in electric shock. If repairs are needed, contact a qualified service provider.
- Unplug the appliance from the socket before cleaning it. Do not use liquid cleaners or aerosols. Use a damp cloth to clean the housing.

Usage:

Note: Before you start verifying a banknote or document, make sure that you know and understand the security features of the banknote or document you are checking. This will help you use the device properly.



I: Lamp on for watermarks and magnetic detection
O: Off
II: UV lamp on

Detection of counterfeit banknotes using ultraviolet light

- Plug in the device and set the switch to the "O" to "II" position.
- Locate the security thread on the banknote using the "Check Security Thread" guide on the front of the device.
- Examine the banknote with a magnifying glass to make sure that the security thread is visible and in the correct place on the banknote.

Magnetic Ink Detection

- Slide the switch from the "O" position to the "I" position.
- Find the magnetic location on the banknote using the currency guide located on the top of the device.
- Slide the magnetic part of the banknote over the magnetic head. If magnetic ink is present, the red indicator lights up and you hear a beep to confirm the authenticity of the banknote.

Watermark and microtext verification

- Slide the switch from the "O" position to the "I" position.
- Locate the watermarks on the banknote using the currency guide located on the top of the device.
- Place the banknote on the circular verification plate and verify the visible watermarks on the banknote to confirm its authenticity.

Verify microtext with a magnifying glass

- Place the banknote or document under the magnifying glass window.

- Visually inspect the microtext and fine lines on the banknote and special documents.

Maintenance:

- Avoid using the device near strong natural or artificial light sources.
- The effect of UV light can be diluted by strong natural or artificial light, which will reduce the visibility of fluorescence on the banknote or document being analyzed.
- Do not use this appliance where it may be exposed to water or other liquids.
- Dust can settle on UV lamps, reducing their brightness. Use a damp, soft cloth to clean. Do not use liquid cleaners or aerosols.
- Unplug the appliance from the electrical outlet before cleaning or replacing the lamp.
- Do not use the appliance if the power cord is damaged or the plug is loose.
- Failure to follow these instructions could lead to electric shock, fire, or other hazards.
- If the appliance will not be used for a long period of time, disconnect the plug from the socket.