User Manual

Encoded proximity card

HD-RWC02

Table of contents

Specifications: 3
Set contents: ..... **Błąd! Nie zdefiniowano zakładki.**
How to use 4

Specifications:

- **Material:** PVC
- **Finish:** White Gloss
- **Operating frequency:** 13.56MHz
- **Card dimensions:** 86 x 54 x 1 mm
- **Chip:** MIfare 1K S50

Set contents:

- 10 encoded RFID cards

How to use

1. **System Integration**

- **System Compatibility:** Make sure that the system with which you intend to use the RFID card (e.g. access control system, time and attendance) supports cards operating at 13.56 MHz.

2. **Using the Card**

- **Access:** To access the protected area, hold the card close to the RFID reader. The reader will automatically scan the card, read the data stored on the chip and verify the user's access permissions.
- **Identification:** In identification systems, the card can also be used to quickly confirm the user's identity, e.g. when recording working time.
- **Card Storage:** To ensure long-term and trouble-free operation of the card, avoid exposure to extreme conditions such as heat, humidity, or direct sunlight, which can damage the RFID chip or antenna.