

Manual

Wired barcode reader **HD67**

Table of contents

Specifications:.....	2
Set contents:.....	3
Master Control Codes.....	4
Setting End Characters.....	4
Beep settings.....	4
Case settings.....	5
Hide leading and trailing characters in a barcode.....	6
Prefix and Suffix Setting.....	7
Appendix No. 1.....	9

Specifications:

- **Warranty:** 2 years
- **Material:** ABS + PC
- **Light Source:** 650-670nm Laser
- **Scanning method:** manual (push-button)
- **Scan confirmation:** two types of emitted sound, LED
- **Read Rate:** 100 times/second
- **Readability Accuracy:** 0.10 mm
- **Reading Distance:** 2.5-600mm
- **Error rate:** 1/800 million
- **Print Contrast:** Min. 30%
- **Interface:** USB
- **Cable length:** 200 cm
- **Ingress protection:** IP54
- **Device dimensions:** 6.5 x 16 x 9 cm
- **Package dimensions:** 21 x 11.5 x 8.5 cm
- **Device weight:** 160 g
- Weight with packaging: 240 g
- Operating temperature: 0 to 45°C
- Storage temperature: -40 to 60°C
- Operating Humidity: 5 to 95%
- Storage Humidity: 5 to 95%
- Readable 1D codes: EAN-8, EAN-13, EAN-128,UPC-A, UPC-E, CODE 128, CODE 39, CODE 93, CODE 11, Industrial 2 of 5, Interleaved 2 of 5 (ITF), Matrix 2 of 5, CODABAR, MSI

Set contents:

- Wired barcode reader
- USB cable
- Manual



Master Control Codes

	
Factory reset	Software version

Setting End Characters


	
CR	ENTER
	
No signs	TAB

Beep settings











	
Beep on	Beep off



Case settings








Hide leading and trailing characters in a barcode

 <p>Hide the last character</p>	 <p>Hide the two trailing characters</p>
 <p>Hide the three trailing characters</p>	 <p>Hide the Four Trailing Characters</p>
 <p>Hide the five trailing characters</p>	 <p>Unhide trailing characters</p>
 <p>Hide the first character</p>	 <p>Hide two initial characters</p>
 <p>Hide the three starting characters</p>	 <p>Hide the four starting characters</p>

 <p>Hide the five starting characters</p>	 <p>Unhide starting characters</p>
--	--

Prefix and Suffix Setting

 <p>Adding a prefix</p>	 <p>Add a suffix</p>
 <p>Exit prefix and suffix adding mode</p>	 <p>Remove all prefixes</p>
 <p>Remove all suffixes</p>	





















In order to set a prefix or suffix, you must first:

- Scan the Add **Prefix** or **Add Suffix code**.
- Then it is necessary to scan the appropriate code to be the prefix or suffix from Appendix No. 1.

- Finally, scan the **Exit Prefix and Suffix mode code** to save the settings and exit the end and start character setting mode.

In case you want to remove the prefixes or suffixes you have added, simply scan the **Remove All Prefixes** or **Remove All Suffixes code**.

Appendix No. 1

 SOH	 STX
 ETX	 EOT
 ENQ	 ACK
 BEL	 Backspace
 TAB	 LF
 VT	 FF
 CR	 SO
 SI	 DLE
 DC1	 DC2
 DC3	 DC4



SOH



ETX



ENQ



BEL



TAB



VT



CR



SI



DC1



DC3



STX



EOT



ACK



Backspace



LF



FF



SO



DLE



DC2



DC4



€



)



+



-



/



1



3



5



7



(



*



,



.



0



2



4



6



8



9



;



=



?



A



C



E



G



I



K



:



<



>



@



B



D



F



H



J



L



M



O



Q



S



U



W



Y



[



]



N



P



R



T



V



X



Z



\



^



-



a



c



e



g



i



k



m



2011, 2012



b



d



f



h





















j



l



n

 o	 p
 q	 r
 s	 t
 u	 v
 w	 x
 y	 z
 {	
 }	 ~
 Delete	 F1



F2



F4



F6



F8



F10



F12



HOME



Delete



Page down



F3



F5



F7



F9



F11



INSERT



Page up



END



Right arrow



Left arrow



Down arrow



Up arrow