

# Statement

---

Programming the  
SPACEBAR as a suffix

**HD67**

To set the SPACEBAR as the suffix on the HD67 reader, scan the following codes one by one.

