

Manual

Displaying the checksum in EAN13 **HD75 code**

In order to activate the EAN13 checksum transmission on the HD75 reader, scan the following codes.



