

Manual

Retail Scale wagPRO-S40

Table of contents

- Specifications: 3
- Set contents:..... 4
- Features: 4
- Pre-launch notes:..... 5
- Starting and using the scale:..... 5
- Transport and storage: 6
- Usage notes:..... 6

Specifications:

- **Warranty:** 1 year
- **Material:** steel, plastic
- **Maximum nominal load:** 40 kg
- **Accuracy:** +/- 2 g
- **Maximum permissible load:** 100% of nominal load
- **Display:** digital, up to five numbers
- **Additional functions:** weight tare, unit price entry, screen backlight
- **Battery Type:** Lead-Acid
- **Power supply:** mains, rechargeable
- **Battery capacity:** 4 Ah (4000 mAh)
- **Battery life:** up to 2 days
- **Standby time:** up to a week
- **Auto Backlight Dimming:** After 10 seconds of inactivity
- **Operating Temperature:** 0-40°C
- **Operating humidity:** up to 85% at 20 °C
- **Device dimensions:** 32 (L) x 33 (W) x 12 (H) cm
- **Dimensions of the weighing platform:** 32 x 23 cm
- **Package dimensions:** 37.5 x 36 x 13 cm
- **Device weight:** 3 kg
- **Weight with packaging:** 3.8 kg

Set contents:

- Shop scale,
- AC adapter,
- Manual.

Features:

- **Measurement accuracy:** +/- 2 g
- **Display:** digital, up to five numbers
- **Battery capacity:** 4 Ah
- **Additional functions:** weight tare, unit price entry, screen backlight

Pre-launch notes:

Place the scale on a stable and flat surface. The bottom four screws must be adjusted so that the scale is in a horizontal position. The scale cannot be used in the tare state for a long time, otherwise the auto-zero function will be unavailable and the zero point will be deviated.

Starting and using the scale:

1. Turn on the scale using the button on the housing. When the power is switched on, the displays show numbers one by one until the zero state is entered and the "Zero" symbol is marked.
 2. **【Zero / Tare】** Key: Sets the weight currently being measured to zero. (Tare setting range: maximum 1/3 of the nominal load)
 - 2.1. Pressing this button during weighing will set the balance window to zero, and the "Zero / Tara" symbol will be illuminated.
 - 2.2. Removing the weight will cause the weight window to display negative values.
- Pressing the **【Zero / Tara】** button again, will set the weight window to zero, and the "Tare" symbol will disappear.
3. **【0~9】** Keys: Enters the unit price, pressing any number key will clear the previous unit price after 3 seconds, and enter the indicated number.
 4. Key **【.】** : Enters fractional values, enter the integer part before pressing and decimal parts after pressing the key.
 5. **【LIGHT Key】** : Screens backlight key. Press this key to turn off the backlight or turn on the backlight. By default, the backlight is automatically invoked at startup.

6. **【SAMPLING/COUNT Key】** : Product counting key. Press this button, put the number of products, enter the number of products placed. Placing consecutive products of one type will allow you to count the number of products placed on the scale.

Transport and storage:

Avoid shocks and moisture during transportation. Avoid strong sunlight and water exposure during storage.

Usage notes:

1. Please read this user manual carefully before using the scale.
2. If the scale has not been used for a long time, please charge the battery at least once every 2 months, and keep the power switch in the "off" state to avoid discharging and damaging the battery.
3. The LCD display of the scale must be operated in intense lighting, it is recommended to run the display backlight in low light conditions.
4. Avoid impact when placing the weighed item on the scale.
5. It is forbidden to use strong chemical solvents to clean the surface.
6. Clean the scale with a dry or slightly damp dish cloth. Washing the scale with water is prohibited and may damage the device.