

Manual

Pocket hook scale up to
50 kg

wagPRO-H50F

Table of contents

Specifications:	3
Set contents:	4
Enable:	4
Unit change:	4
Weight value lock:	4
Weighing:	4
Disable:	5
Backlight:	5
Safety:	5

Specifications:

- **Warranty:** 1 year
- **Material:** ABS, steel hook
- **Colour:** Orange
- **Maximum nominal load:** 50 kg
- **Measurement accuracy:** 1g
- **Maximum permissible load:** 100% of nominal load
- **Scale Legalization:** No
- **Display:** LCD 32 x 18 mm
- **Display backlight:** Light blue
- **Additional features:** unit swapping
- **Available weight units:** g, kg, lb, jin, oz
- **Power supply:** 1x CR2032 battery
- **Device dimensions:** 11.5 x 6 x 2.5 cm
- **Package dimensions:** 14 x 8 x 4 cm
- **Device weight:** 300 g
- **Weight with packaging:** 400 g

Set contents:

- Scale with hook,
- 1x CR2032 battery

Enable:

Place the scale in an upright position without weight on the hook. Press the "ON/OFF" button, the screen will show (8888). Wait 2-3 seconds for the screen to display (0.00 or 0.000). Then the scale will be ready for use.

Unit change:

By clicking on the "UNIT" button you can select the unit between grams (g), kilograms (kg), pounds (lb), half kilograms (Jin), ounces (oz) when enabled.

Weight value lock:

Press the Power On/ T button during weighing, and the result screen will be locked. Once locked, press the "ON/OFF" button to unlock again and you can perform another weigh-in.

Weighing:

Turn on and wait for auto-zeroing, then hang the goods on the hook and the weight will be displayed. Wait until the goods are stationary (no longer shaking), the weight value will be locked if the weight value lock function is enabled, and "LOCK" appears on the screen. Then press the "ON/OFF" button to unlock the value and weigh more. The maximum load shall not exceed the full load.

Disable:

Press "ON/OFF" to turn off

Backlight:

The backlight will turn off if the scale is not started or the weight on the hook is stable for more than 3 seconds. When you press any button or change the ground on the hook, the backlight will turn on again.

Safety:

1. When powered on, the scale should be upright.
2. To weigh the ring, hold the ring or place aids on it. Do not hold the enclosure while weighing, as this will cause the deviation to be exceeded or the scale to be damaged.
3. Avoid strong shock or vibration during operation.
4. The housing is made of ABS plastic. Please use a soft cloth with water or detergent to clean, do not use corrosive substances such as benzene, solvent, etc.
5. Do not disassemble the scale by yourself if there is a fault that is not caused by man-made. You should send it back to our company.