

Manual

Desk Mount Dual monitors **SolidHand-SG02**

Table of contents

Specifications:.....	2
Set contents:.....	3
General comments	4
Maintenance.....	4
Mounting the mount	5

Specifications:

- **Warranty:** 1 year
- **Color:** Black
- **Number of monitors:** 2
- **Min. monitor diagonal:** 13"
- **Max. monitor diagonal:** 27"
- **Monitor Weight:** 2-6kg
- **Height adjustment:** Gas spring assisted
- **Arm swivel range:** 360°
- **Monitor Rotation Range:** -90° ~ 90°
- **Monitor tilt range:** -45° ~ 90°
- **Min. arm overhang:** 160 mm
- **Max. arm outreach:** 410 mm
- **Package dimensions:** 400 x 295 x 125 mm
- **Handle weight:** 2.7 kg
- **Weight with packaging:** 3.5 kg

Set contents:

- Monitor Mount
- Screws and mounting washers
- Manual

General Considerations

Read the entire user manual before beginning installation and assembly. If you have any questions about instructions or warnings, please contact your dealer for assistance.

WARNING: Using the product with products heavier than the indicated rated weights may cause the handle to become unstable, resulting in possible accidents.

- Fasteners must be fastened in accordance with the installation instructions. Improper installation may result in hardware damage or serious personal injury.
- Use protective equipment and appropriate tools. This product should only be installed by qualified persons.
- Ensure that the supporting surface can securely support the combined weight of the equipment and the included components.
- Use the included mounting screws and DO NOT TIGHTEN THE MOUNTING SCREWS WITH ALL THE FORCE.
- This product contains small items that may be a choking hazard if swallowed. Keep these items away from children.
- This product is intended for indoor use only. Use of this product outdoors may lead to its destruction and cause personal injury.

IMPORTANT: Make sure you receive all parts according to the component checklist before installation. If any parts are missing or damaged, contact your dealer for a replacement.

Maintenance

At regular intervals (at least every three months), check that the bracket is properly attached and safe to use.

Mounting the mount

Set contents:



