

# User Manual

---

## QR code reader in metal housing HD201

## Table of contents

Specification.....	3
The set contains:.....	4
Features: .....	4
Basic Configuration Codes.....	5
Scan Modes.....	5
Trailing character settings .....	6
Interface settings .....	8
Reverse Code Scanning.....	8

## Specification

- **Warranty:** 2 years
- **Housing:** Metal
- **Light source:** 630nm +/- 10nm LED laser
- **Sensor:** CMOS
- **Scan Method:** Manual/Automatic
- **Print contrast:** min 25%
- **Current consumption:** 250 mA
- **Interface:** USB, Virtual COM
- **Cord length:** 200 cm
- **Ingress protection:** IP54
- **Device dimensions:** 7 x 5 x 2.6 cm
- **Package dimensions:** 27.5 x 18 x 10 cm
- **Weight:** 280 g
- **Package weight:** 360 g
- **Operating temperature:** 0 to 45°C
- **Storage temperature:** -20 to 70°C
- **Operating humidity:** 5% to 95%
- **Read 1D codes:** CodaBar, Code 11, Code 32, Code 39, Code 93, Code 128, IATA 2 of 5, Interleaved 2 of 5 (ITF), GS1 DataBar, HongKong 2 of 5, Matrix 2 of 5, MSI Plessey, NEC 2 of 5, Pharmacode Plessey, Straight 2 of 5, Telepen, Trioptic, UPC/EAN/JAN, Codablock F, microPDF, GS1 Composite
- **Read 2D codes:** MaxiCode, DataMatrix (ECC 200), QR Code, microQR, Aztec, HanXin, GoCode

## The set contains:

- Wired Barcode Reader
- USB cable
- Manual

## Features:

- Metal casing
- High-performance scan sensor
- Drop resistance

# Basic Configuration Codes



Factory reset



Turn on crosshair



Disable crosshair

# Scan Modes



Manual Scan Mode



Automatic scanning enabled



Automatic scanning disabled

## Trailing character settings



Add CR



Delete CR



Add LF



Remove LF



Add CR+LF



Remove CR+LF

# Audio settings

## Beep duration



Normal



Short

## Tone



3.1 kHz



1.6 kHz



2.0 kHz



2.4 kHz

# Interface settings



USB Mode



Virtual COM Mode

## Baud



300 bps



600 bps



2400 bps



4800 bps

## Reverse Code Scanning



Enabled



Disabled