

User manual

Kitchen scale **wagPRO-K5B**

Spis treści

- Specification:..... 3
- Kit contents:..... 4
- Features: 4
- Power supply:..... 4
- Functions:..... 4
- Safety precautions:..... 5

Specification:

- **Warranty:** 1 year
- **Material of construction:** ABS
- **Maximum load:** 5 kg
- **Measurement accuracy:** 0.1 g
- **Display:** 0.6" LCD
- **Additional features:** scale tare, unit conversion, auto shut-off, low battery indicator
- **Available weighing units:** g, oz, ml, ct, kg
- **Power supply:** 2 x 1.5V/AAA battery
- **Operating temperature:** 0 - 40°C
- **Storage temperature:** - 20 - 60°C
- **Operating humidity:** 0 to 95%
- **Storage humidity:** 0 to 95%
- **Device dimensions:** 21 x 14.5 x 2 cm
- **Package dimensions:** 21.5 x 17.5 x 3.5 cm
- **Weight of the device:** 370 g
- **Weight with packaging:** 460 g

Kit contents:

- Kitchen scale,
- 2 x AAA battery,
- user manual.

Features:

- **Measurement accuracy:** +/- 0.1 g
- **Display:** LCD, backlit
- **Power supply:** 2 x 1.5V/AAA battery
- **Additional features:** scale tare, unit conversion, automatic shut-off, low battery indicator

Power supply:

To start the device, place the included batteries in the scale.

Operation

1. Place the kitchen scale on a hard and flat surface.
2. Press the "ON/OFF" button, the scale will be zeroed in 3 seconds.
3. Place the weighed object in the container, the scale will appear on the display.

Functions:

Tare

Place the container on the pan, when the weight reading is stable, press the TARE button. After a moment, the weight of the container will be subtracted.

Changing units

By pressing the "MODE" button, it is possible to select the unit between g or oz.

Overload indicator

When the scale is overloaded (the weight of the product on the pan exceeds 5 kilograms), the following message "EEEE" will appear on the screen.

Safety precautions:

1. Place the scale on a hard, flat surface to ensure the greatest accuracy and repeatability.
2. Clean the scale with a damp cloth, not allowing water to enter the scale.
3. Do not use chemical abrasive cleaners to clean the balance.
4. Do not let the scale get soaked with water, as this may damage the electronics.
5. Do not store the scale in an upright position when not in use, as this will drain the batteries.
6. If the scale will not be used for a long time, remove the batteries from the scale
7. Handle the scale with care, as it is a precision instrument.